

JOINT ADVANCED MATERIALS & STRUCTURES
CENTER OF EXCELLENCE

Improving Adhesive Bonding of Composites Through Surface Characterization

November 1, 2011

Ashley Tracey, Lisa Carlson, Brian D. Flinn
University of Washington



Improving Adhesive Bonding of Composites Through Surface Characterization

- Motivation and Key Issues
 - Most important step for bonding is SURFACE PREPARATION!!
 - Inspect the surface prior to bonding to ensure proper surface preparation
- Objective
 - Develop QA technique for surface preparation
- Approach
 - Investigate different surface preparations and process variables using laboratory and handheld devices

FAA Sponsored Project Information

- Principal Investigators & Researchers
 - Brian D. Flinn (PI)
 - Ashley Tracey (PhD student, UW-MSE)
 - Lisa Carlson (undergraduate, UW-MSE)
- FAA Technical Monitor
 - David Westlund
- Other FAA Personnel Involved
 - Larry Ilcewicz
- Industry Participation
 - Toray Composites
 - Precision Fabrics & Richmond Aerospace & Airtech International
 - The Boeing Company (Kay Blohowiak, Peter Van Voast, William Grace, Liz Castro, John Spalding, Mary Vargas & Paul Shelley)

2010-2011 Statement of Work

	Surface Characterization/QA Technique			
	Contact Angle		FTIR	
	Goniometer	Surface Analyst	ATR	Exoscan
Cure Temp and Dwell Time	✓	✓		
Peel Ply Prep	✓	✓	✓	✓
Si Contaminants	✓	✓	✓ (Boeing)	
Peel Ply Orientation	✓	✓ No effect	N/A	
Abraded Texture	✓			
Scarfed Surfaces/ Repair				

✓ = work completed

Surface Characterization

For a good bond: 1) Adhesive must wet substrate and 2) strong chemical bonds between adhesive and substrate

Surface Energy

- Ability of adhesive to wet substrate
- Characterized by contact angle
- Contamination can lower surface energy

Surface Chemistry


- Availability of chemical bonds at the surface
- Characterized by FTIR
- Contamination changes surface chemistry

Surface preparation influences the energetics and chemistry of a substrate

Contact Angle Methodology (Surface Energy)

VCA Optima Goniometer

- Bench top device
- Lab research



<http://www.astp.com/contact-angle/optima>

Brighton Surface Analyst™


- Handheld device
- In-field inspection




<http://www.btgnow.com>

Contact Angle Methodology

Goniometer




Drop application: dispense drop, raise surface




Side-view of drop as viewed from goniometer camera

- 4 fluids
- 10 drops/fluid/substrate
- Calculate surface energy

Surface Analyst™



Drop application: dynamically apply 20 small drops to form 1 drop



Top-view of drop as viewed from Surface Analyst camera

Note: rectangle is reflection from camera light

- Water only
- 20 drops/substrate
- Average contact angle

FTIR Methodology

Interaction between IR beam and material produce spectra displaying chemical bonds in material

Bruker Vertex 70 FTIR

- Bench top device
- Attenuated total reflectance (ATR)



<http://www.aoc.kit.edu/english/612.php>

Agilent Technologies Exoscan™ FTIR


- Handheld device
- Specular reflectance



<https://www.chem.agilent.com>

FTIR Methodology


Vertex 70



An IR beam path for single bounce ATR

- Single bounce MIR diamond ATR
- Use pressure clamp to ensure good contact with substrate

Exoscan™



An IR beam path of specular reflectance

- MIR specular reflectance
- Non-contact

Experimental Overview

Assess potential QA methods ability to identify variations in process conditions



- Surface Preparations:
 - Polyester peel ply, nylon peel ply, SRB release ply
- Peel Ply Contamination:
 - Various levels of siloxane contamination
- Abrasion Variables:
 - Grit size: 80, 220, 400
 - Orientation

Materials and Process


- Toray 3900/T800 unidirectional laminates
- Peel ply surface prep
 - Precision Fabric Group 60001 polyester peel ply
 - Precision Fabric Group 52006 nylon peel ply
 - Precision Fabric Group SRB release ply
- Autoclave cure (177°C, 0.6MPa)
- Fluids used for contact angle analysis:
 - De-ionized water (DI water)
 - Ethylene Glycol (EG)
 - Glycerol (Gly)
 - Diiodomethane (DIM)
 - Formamide (Form)
- 3M Al₂O₃ grit abrasive cloth

Characterization of Peel Ply Preparation

- Affect of peel ply type on surface characteristics
 - Polyester peel ply
 - Nylon peel ply
 - SRB release ply




Contact Angle Results (DI H₂O)



✓ Both methods detect differences in peel ply type


FTIR-ATR Surface Chemistry Results



✓ Differences in surface chemistry are evident

FTIR-Exoscan™ Surface Chemistry Results

Multivariate Analysis of Specular Reflectance Spectra



Partial least squares with Savitsky-Golay first derivative and 5 smoothing point preprocessing 2-principal component model

- Method written for Exoscan™ to identify peel ply type
- ✓ Exoscan™ can be used to identify different peel ply/release ply surface preps

In collaboration with Paul Shelley, Boeing

Characterization of Surface Preparation

Effect of Peel Ply Contamination

- Contaminants are detrimental to bonding
- Previous research at Boeing showed that FTIR-ATR can detect contamination levels >0.5% on the cured laminate¹
 - Can contact angle be used to identify surface contamination?

Mix Solids Target Level (% siloxane)

0% (control)

0.0001%

0.001%

0.01%

0.05%

0.1%

0.2%

0.3%

0.4%

0.5%

1%


2%



Detrimental to Bonding¹


¹ VanVoast, P.J., P.H. Shelley, R.L. Blakely, C.B. Smith, M.P. Jones, A.C. Tracey, B.D. Flinn, G. Dillingham, B. Oakley. "Effect of Varying Levels of Peel Ply Contamination on Adhesion Threshold." SAMPE 2010 – Seattle, WA May 17-20, 2010.

Goniometer Results: Wettability Envelopes



✓ Contact angle sensitive to $< 0.1\%$ Si contamination



Contact Angle Results



✓ Both methods detect contamination below that which affects bonding (1%)

Surface Roughness


- Previous research showed contact angle changes at different peel ply angles with respect to goniometer camera due to noncircular drops



- Contact angles highest at 0° or 90° orientation, lower at all other orientations
 - Measure contact angle at 0° or 90° orientation

Abrasion Texture: Stereoscope Images

- Want to further understand effect of roughness
 - Manual abrasion (surface prep)
 - As tooled surfaces abraded with 80, 220 and 400 grit abrasive cloth parallel to fiber (ℓ) direction
 - Measure contact angle at longitudinal (ℓ) and transverse (t) views



Effect of Surface Roughness on Contact Angle

DI H₂O

Ethylene Glycol





Formamide

Glycerol

80 grit

$$R_a(\vartheta) = 94.6 \pm 16.6 \mu\text{in}$$





$$R_a(\ell) = 43.6 \pm 20.8 \mu\text{in}$$



220 grit

$$R_a(\vartheta) = 63.4 \pm 9.1 \mu\text{in}$$





$$R_a(\ell) = 40.7 \pm 8.7 \mu\text{in}$$



400 grit


$$R_a(\vartheta) = 35.0 \pm 4.9 \mu\text{in}$$

$$R_a(\ell) = 19.8 \pm 3.3 \mu\text{in}$$



Note: white circles on drops are reflection of camera light



Contact Angle: Effect of Surface Roughness




- ✓ Transverse (t) contact angle lower than longitudinal (l)
- Contact angle decreases with increased roughness
 - Exception: EG – viscosity effect?

Surface Roughness and Contact Angle

- Fluids form noncircular drops on surfaces
 - Fluid flows down path of least resistance \rightarrow θ contact angle lower
 - Fluid arrested at peaks between grooves \rightarrow ℓ contact angle higher



DI H₂O on 220 grit surface viewing along θ



DI H₂O on 220 grit surface viewing along ℓ

Summary

	Surface Characterization/QA Technique			
	Contact Angle		FTIR	
	Goniometer	Surface Analyst	ATR	Exoscan
Cure Temp and Dwell Time	✓	✓	TBD	TBD
Peel Ply Prep	✓	✓	✓	✓
Si Contaminants	✓	✓	✓ (Boeing)	TBD
Peel Ply Orientation	✓	✓ No effect	N/A	TBD
Abraded Texture	✓			
Scarfed Surfaces/ Repair	TBD	TBD	TBD	TBD

More work is necessary, but contact angle and FTIR have a potential for QA methods

Looking Forward

- Benefit to Aviation
 - Better understanding of peel ply surface prep.
 - Guide development of QA methods for surface prep.
 - Greater confidence in adhesive bonds
- Future needs
 - Application to other composite/surface prep./adhesive systems (repair, paste adhesive, etc.)
 - Model to guide bonding based on characterization, surface prep. and material properties
 - QA methods to ensure proper surface for bonding

Acknowledgements

- FAA, JAMS, AMTAS



- Boeing Company



- Precision Fabric Group



- Richmond Aircraft Products



- Airtech International




- Prof. Mark Tuttle (UW)

- Paul Shelley (Boeing)



Thank you

Questions and comments welcome



JOINT ADVANCED MATERIALS & STRUCTURES
CENTER OF EXCELLENCE

