

Composite Thermal Damage Measurement with Handheld FTIR

November 14, 2013

B.D. Flinn, T. Howie, A.C. Tracey, D. Pate,
J.T. Morasch, E. Roberts
University of Washington

Composite Thermal Damage Measurement with Handheld FTIR

- Motivation and Key Issues
 - Damage detection in composites requires different techniques than metals
 - Incipient thermal damage occurs below traditional NDE detection limits
- Objective
 - Determine if handheld FTIR can detect thermal damage and guide repair
- Approach
 - Characterize panels with controlled thermal damage and perform repair based on FTIR inspection

FAA Sponsored Project Information


- Principal Investigators & Researchers
 - Brian Flinn (PI)
 - Ashley Tracey (PhD student, UW-MSE)
 - Tucker Howie (PhD student, UW-MSE)
- FAA Technical Monitor
 - David Galella (year 3)
 - Paul Swindell (year 1 & 2)
- Industry Participation
 - The Boeing Company (Paul Shelley, Paul Vahey)
 - Sandia National Lab (Dennis Roach)
 - Agilent (formerly A2 Technologies)

Background

- Continuation of existing project (year 3 of 3)
- Years 1 and 2 (A2 Technologies, Boeing and U of DE)
 - Characterization of homogeneous thermal damage
 - Ultrasound
 - Short beam shear (SBS)
 - Microscopy
 - Handheld FTIR (ExoScan)
 - Calibration curve for FTIR detection of thermal damage (SBS data)
 - Mapped surface of localized thermal damage
- Year 3 (UW and Boeing)
 - 3-D characterization of localized thermal damage
 - Contact angle and fluorescence spectroscopy
 - FTIR guided scarf repair
 - Test repair

Thermal Damage vs. Detection Method


Short Beam Shear Strength Retention vs. Temp./Time – Epoxy 1



- SBS, ultrasound, and microscopic analysis of composites with thermal damage
 - Properties degrade before detection possible → need method to detect incipient thermal damage (ITD)

Thermal Damage vs. Detection Method

Short Beam Shear Strength Retention vs. Temp./Time – Epoxy 1



- SBS, ultrasound, and microscopic analysis of composites with thermal damage
 - Properties degrade before detection possible → need method to detect incipient thermal damage (ITD)

Summary of Work Completed

| | FTIR | Contact Angle | Fluorescence |
|-----------------------------|--|---------------|--------------|
| Thermal Damage | ✓ | ✗ | ✗ |
| Resin rich (tooled) surface | oxidation peaks characterized | | |
| Fiber rich (sanded) surface | oxidation peaks absent → multivariate analysis (MVA) | | |
| Fiber orientation | signal varies with orientation | | |
| Surface finish | can only compare surfaces with MVA when surface finish is same | | |

Summary of Work Completed

| | FTIR | Contact Angle | Fluorescence |
|------------------------------------|---|---------------|--------------|
| Thermal Damage | ✓ | ✗ | ✗ |
| Resin rich (tooled) surface | oxidation peaks characterized | | |
| Fiber rich (sanded) surface | oxidation peaks absent → multivariate analysis (MVA) | | |
| Fiber orientation | signal varies with orientation | | |
| Surface finish | can only compare surfaces with MVA when surface finish is same | | |

Experimental Overview

- Thermally Damaged SBS samples
 - FTIR measurements on SBS samples
 - Develop calibration curve for FTIR from SBS values
 - Predict evaluation set to validate model
 - Composite panel locally damaged
 - Panel Mapped using FTIR
 - Panel cut up for mechanical testing
 - SBS
 - T_g (DMA)
-

- Toray T800/3900 composites with various levels of thermal damage
 - SBS samples provided from Year 1 & 2 research
 - SBS samples thermally exposed in air
 - Locally damaged panels heated in air – UW/Boeing
- Sand SBS surfaces with 180 grit Al_2O_3 sanding pads
- Measure sanded surface with diffuse reflectance FTIR
 - 3 measurements per sample
 - 3 samples per time/temp
- Use MVA to develop calibration curve for thermal damage
 - GRAMS IQ software


} 9 measurements

Materials and Process – FTIR

- Mid-IR data region: 4000 cm^{-1} to 650 cm^{-1}
- Diffuse reflectance sampling interface
- Data collection: 90 coadded scans with 16 cm^{-1} resolution for background and specimen




ExoScan FTIR




An infrared beam path for diffuse reflectance

Resin Rich vs. Fiber Rich Surfaces

- Resin rich surfaces: oxidation peaks increase with damage
- Fiber rich surfaces: oxidation removed by sanding
 - Need MVA to determine differences in spectra and correlate to SBS data




9




Spectral Analysis

- FTIR spectra of CFRP surfaces complex
 - Multiple constituents → many spectral peaks
- How to analyze spectra with confidence?
 - Multivariate analysis!
- Principal Component Analysis (PCA)
 - Exploratory to identify trends
 - Peak locations and intensities
 - Used to develop models




Effect of Sanding Variables on FTIR

Temperature




Grit size




- Variables: temperature, method (hand vs. orbital), direction of sanding, grit size

Effect of Sanding Variables on FTIR

Direction of Sanding



Sanding Method




- FTIR Results influenced by sanding technique
- Measure consistent surfaces and develop model


Developing FTIR Model

- SBS samples sanded and measured with FTIR
- FTIR spectra processed to remove baseline effects
 - 1st derivative with Savitzky-Golay 7pt smoothing
- Partial Least Squares model developed using MVA on processed spectra


Raw Spectra



Processed Spectra




FTIR Model








✓ Data fits model

Model Validation




- Model used to predict SBS retention in independent evaluation set
- Error in model determined

Localized Heat Damage – Process




Localized Heat-Damage Mapping



- Different levels of thermal damage detected by FTIR
 - Cut panels into SBS and dynamic mechanical analysis (DMA) samples for mechanical testing

SBS and DMA Testing

- Damaged panel cut into SBS and DMA coupons
- Testing in progress
- Compare SBS and T_g to determine best method to correlate to FTIR



Summary

- FTIR measurements sensitive to surface finish
 - Need to test samples with consistently sanded surfaces
- Calibration model developed from SBS samples
 - Model predicted evaluation set well
- Panels created with localized thermal damage and surface mapped with FTIR
- SBS and DMA testing in progress to correlate mechanical damage to FTIR spectra


Future Work

- Map thermally damage panels provided from Years 1 & 2 with FTIR
- Determine mechanical test to correlate damage to spectra
- Characterize thermally damage of panels provided from Years 1 & 2
- Perform scarfed repair guided by FTIR
- Test scarfed repair


Looking Forward

- Benefit to Aviation
 - Improved damage detection
 - Greater confidence in repairs
 - Future needs
 - Application to other composite systems
 - Other applications of handheld FTIR
 - Chemical damage
 - Surface prep for bonding
-


Fluorescent Thermal Damage Probe





Probe-doped coating
 1 hr @ 450 °F



Thermal exposure on composite



Fluorescence inspection



Funded by: The Boeing Co.

Acknowledgements

FAA, JAMS, AMTAS 

Boeing Company 

- Paul Vahey, Paul Shelly, Greg Werner, Megan Watson, Jim Chanes

Sandia National Labs 

Agilent Technologies  **Agilent Technologies**

UW MSE 